



# VEHLIVE



## User Manual

### GL50449 TPMS Reset Tool

# 1

## Enter Learning Mode

1. Make the gear in P position.
2. With the ignition switch to OFF, press and release the brake pedal.
3. Turn the ignition switch from the OFF position to the RUN position 3 times and end at RUN position.
4. Depress and release the brake pedal.
5. Ignition to OFF position.
6. Ignition goes from the OFF position to the RUN position 3 times and ends at RUN position.
7. Horn will ring once and the TPMS indicator flashes, then the learning mode has been successfully entered. If equipped, the message center will display the front left (LF) tire.



# 2


## To Rest TPMS Sensors

1. Starting relearn process from left front tire, point antenna on correct position. Press & release power button. Once the speaker chirped, move to the next tire.
2. Follow this order to rest TPMS sensors: Front left, front right, rear right, rear left.
3. After all sensors reseted, the car horns twice means TPMS re-learn finished.



## Tips for user:

1. Please make sure antenna fit in CORRECT position.





2. Please make sure the 9V battery is with enough power.



Note: Battery not included

3. Sensors should be original OEM sensors which well programmed.

